

## FILLING INSTRUCTIONS

1. Unscrew tapered end of your pen and pull out plunger to its full length.
2. Immerse only the tip in the ink until point is half covered.
3. Push plunger all the way down just once. Hold for ten seconds as the pen fills completely. (Note: pen fills on the downstroke.) Tighten plunger knob.
4. Always use SHEAFFER'S 'Scrip' Writing Fluid

## TO REPLACE POINT UNIT

1. Empty pen by pushing plunger down.
2. Unscrew the point from gripping section.
3. Screw new point into pen. Tighten securely.

Matching pencils are available.

# SHEAFFER'S

1  
Value



\$1  
Value

# FREE EXTRA POINT

Hand this card to salesperson and receive an extra FREE point (\$1 value) in style of your choice.

\$1.00  
Value